


TRAP-TEE

INSTALLATION



Installation Details



TABLE OF CONTENTS

PAGE NUMBER:	DETAIL DESCRIPTION
A-1.....	TABLE OF CONTENTS
A-2.....	GENERAL NOTES
B-1.....	EAVE AND VALLEY FASTENER PATTERNS
C-1.....	FIXED EAVE DETAIL
C-2.....	FLOATING EAVE DETAIL
C-3 & C-4.....	FIXED EAVE with GUTTER DETAIL
C-5.....	FLOATING EAVE with GUTTER DETAIL
C-6.....	RAKE DETAIL
C-7.....	RAKE (OFF MODULE) DETAIL
C-8.....	RAKE TIE-IN DETAIL
C-9.....	RAKE TIE-IN (OFF MODULE) DETAIL
C-10 & C-11.....	FIXED RIDGE DETAIL
C-12 & C-13.....	FLOATING RIDGE DETAIL
C-14.....	FIXED HIGH SIDE TIE-IN DETAIL
C-15.....	FLOATING HIGH SIDE TIE-IN DETAIL
C-16.....	HIGH EAVE DETAIL
C-17.....	DEKTITE DETAIL
C-18 & C-19.....	TYPICAL TRIM LAP DETAILS

GENERAL NOTES

The details shown on the following pages are suggestions or guidelines for installing the Trap-Tee roof panel system. The installation details shown here are proven methods of construction, but they are not intended to cover all building requirements, designs or codes. The details may require changes or revisions due to individual project conditions.

Installation procedures shall be in accordance with the manufacturer's printed instructions, details or approved shop drawings. Installers should thoroughly familiarized themselves with all instructions prior to beginning the installation process.

The designer/installer is responsible to ensure the following:

That the details here meet the particular building requirements.

Awareness of and allowance for expansion/contraction of the roof panels.

That adequate water tightness is maintained.

That a proper uniform substructure is used to avoid panel distortion and that the substructure meets necessary code requirements.

That all supporting members have been examined and are straight, level and plumb.




McElroy Metal can provide all flashings and accessories shown in the installation drawings unless noted otherwise. Panels, flashing and trim shall be installed true and in proper alignment with any exposed fasteners equally spaced for the best appearance. Sealant shall be field applied on a clean, dry surface.

Some field cutting and fitting of panels and flashings is to be expected and to be considered a part of normal installation work. Workmanship shall be of the best industry standards and with installation performed by experienced metal craftsmen.

Oil canning of metal panels is in the product and is not a cause for rejection. Striated panels are recommended as the reduce the appearance of oil canning.

Contents of this manual are subject to change without notice. To confirm this book is the most current copy, please visit McElroy Metal's website at www.mcelroymetal.com.

EAVE FASTENER PATTERN



***NOTE:**
IF ANGLE OF VALLEY CAUSES FASTENERS TO EXCEED 4" O.C., PLACE ADDITIONAL FASTENERS IN BETWEEN OTHER FASTENERS AS SHOWN AS TO NOT EXCEED 4" O.C. SPACING.

FIXED EAVE DETAIL

FIXED EAVE DETAIL

****DIMENSION IS DETERMINED
BY THICKNESS OF WALL
PANEL**



**TURN SEAM CAP
3/4" DOWN TO CLOSE
OFF END OF SEAMS**

**1/4-14 X 1 1/4" TEK2 ZAC
FASTENER (SEE FASTENER
PATTERN ON PAGE B-1)**

**INSIDE CLOSURE W/ 1"
ROLL TAPE SEALANT
(CONT. ALONG TOP & BOTTOM
OF CLOSURES)**

**1/4-14 X 7/8" LAP TEK
FASTENER (@ MAJOR RIBS)**

ALTERNATE EAVE TRIM (MT-28)

— TRAP-TEE SEAM CAP

– TRAP-TEE PANEL

**- TEMPORARY FASTENER
(3 PER 10'-0" TRIM PIECE
PLACE AT SEAM LOCATIONS)**

**EAVE PLATE
MT-185**

**- 1/4-14 X 1 1/4" HWH TEK2
FASTENERS (@ 1'-0" O.C.)**

- **STRUCTURAL EAVE MEMBER**


**- OUTSIDE CLOSURE
(RECOMMENDED)**

- WALL FASTENER

- **WALL PANEL**


EDGE OF EAVE PLATE

OUT TO OUT OF STEEL




ALTERNATE EAVE TRIM (MT-28)


- NOTES:**
- 1. Eave Plate to run from steel line to steel line.**
 - 2. Alternate Eave Trim (MT-28) to run from out of wall to out of wall.**
 - 3. Attach Alternate Eave Trim (MT-28) to Eave Plate with temporary fasteners. Attach to wall panel at major ribs with 1/4-14 x 7/8" Lap Tek fasteners.**
 - 4. Trim pieces lap 2". Apply 3/32" x 3/8" Butyl Tape or Butyl Tube Sealant in trim laps and Pop Rivet trims as shown on page C-17.**
 - 5. Apply continuous run of 3/32" x 1" Roll Tape Sealant on top of Simple Eave Trim. Install Inside Closures on top of Tape Sealant, then apply a continuous bead of 3/32" x 1" Roll Tape Sealant to the top of Inside Closures.**
 - 6. Install Trap-Tee Panels with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners as shown on page B-1.**





*NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.




- NOTES:**
1. Floating Eave Plate to run from steel line to steel line.
 2. Alternate Eave Trim to run from out of wall to out of wall.
 3. Attach Alternate Eave Trim to Floating Eave Plate with temporary fasteners. Attach to wall panel at major ribs with 1/4-14 x 7/8" Lap Tek fasteners.
 4. Trim pieces lap 2". Apply 3/32" x 3/8" Butyl Tape or Butyl Tube Sealant in trim laps and Pop Rivet trims as shown on page C-17.
 5. Apply continuous run of 3/32" x 1" Roll Tape Sealant on top of Alternate Eave Trim. Install Inside Closures on top of Tape Sealant, then apply a continuous bead of 3/32" x 1" Roll Tape Sealant to the top of Inside Closures.
 6. Install Trap-Tee Panels with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners as shown on page B-1.



**DIMENSION IS DETERMINED
BY THICKNESS OF WALL
PANEL





ALTERNATE EAVE TRIM
(MT-28)




7" BOX GUTTER

- NOTES:**
1. Eave Plate to run from steel line to steel line.
 2. Alternate Eave Trim (MT-28) to run from out of wall to out of wall.
 3. Attach Alternate Eave Trim (MT-28) to Eave Plate (MT-185) with temporary fasteners. Attach to wall panels major ribs with 1/4-14 x 7/8" Lap Tek fasteners.
 4. Trim pieces and Gutter lap 2". Apply 3/32" x 3/8" Butyl Tape or Butyl Tube Sealant in trim laps and Pop Rivet trims as shown on page C-17.
 5. Apply continuous run of 3/32" x 1" Roll Tape Sealant on top of Alternate Eave Trim. Install Inside Closures on top of Tape Sealant, then apply a continuous bead of 3/32" x 1" Roll Tape Sealant to the top of Inside Closures.
 6. Install Trap-Tee Panels with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners as shown on page B-1.


*NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.




- NOTES:**
1. Eave Plate to run from steel line to steel line.
 2. Alternate Eave Trim (MT-28) to run from out of wall to out of wall.
 3. Attach Alternate Eave Trim (MT-28) to Eave Plate (MT-185) with temporary fasteners. Attach to wall panels major ribs with 1/4-14 x 7/8" Lap Tek fasteners.
 4. Trim pieces and Gutter lap 2". Apply 3/32" x 3/8" Butyl Tape or Butyl Tube Sealant in trim laps and Pop Rivet trims as shown on page C-17.
 5. Apply continuous run of 3/32" x 1" Roll Tape Sealant on top of Alternate Eave Trim. Install Inside Closures on top of Tape Sealant, then apply a continuous bead of 3/32" x 1" Roll Tape Sealant to the top of Inside Closures.
 6. Install Trap-Tee Panels with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners as shown on page B-1.




- NOTES:**
1. Floating Eave Plate to run from steel line to steel line.
 2. Alternate Eave Trim to run from out of wall to out of wall.
 3. Attach Alternate Eave Trim to Floating Eave Plate with temporary fasteners. Attach to wall panel at major ribs with 1/4-14 x 7/8" Lap Tek fasteners.
 4. Trim pieces lap 2". Apply 3/32" x 3/8" Butyl Tape or Butyl Tube Sealant in trim laps and Pop Rivet trims as shown on page C-17.
 5. Apply continuous run of 3/32" x 1" Roll Tape Sealant on top of Alternate Eave Trim. Install Inside Closures on top of Tape Sealant, then apply a continuous bead of 3/32" x 1" Roll Tape Sealant to the top of Inside Closures.
 6. Install Trap-Tee Panels with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners as shown on page B-1.



*NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.



- NOTES:**
1. MT-183 (Rake Trim), MT-156 (Rake Support Cleat) and MT-SLOT-300 (Starter Zee for 300 Series Panel with 1/4" Offset Clip) to run from eave to ridge.
 2. Attach MT-SLOT-300 (Starter Zee for 300 Series Panel w/ 1/4" Offset Clip) to decking with 1/4-14 x 1 1/4" HWH Tek2 with Shoulder Fasteners at 1'-0" O.C.
 3. Apply two (2) continuous beads of 3/16" x 7/8" Double Bead Tape Sealant to the vertical leg of the Trap-Tee panel. Install Trap Tee panel and hold in place on the Starter Zee with clamps. Fasten panel to Starter Zee with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners at 1'-0" O.C.
 4. Apply a continuous bead of 3/32" x 1" Roll Tape Sealant to the top of the Starter Zee and attach MT-183 (Rake Trim) with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners at 1'-0" O.C.
 5. Trim pieces lap 2". Apply 3/32" x 3/8" Butyl Tape or Butyl Tube Sealant in trim laps and Fasten to trims.



3/32" X 1" ROLL TAPE SEALANT
(CONT. ALONG LENGTH OF RAKE)

2 ROWS OF 3/16" X 7/8"
DOUBLE BEAD TAPE SEALANT
(CONT. ALONG LENGTH
OF RAKE)

RAKE TRIM
(MT-183)

RAKE SUPPORT
CLEAT (MT-156)

STARTER ZEE FOR 300 SERIES
PANEL W. 1/4" OFFSET CLIP
(MT-SLOT-300)

43D POP RIVET
(@ MAJOR RIBS)

OUTSIDE CLOSURE
(RECOMMENDED)

1/4-14 X 1 1/4" HWH TEK2
W/ SHOULDER FASTENERS
(@ 1'-0" O.C.)

RAKE ANGLE

WALL PANEL


1/4-14 X 1 1/4" TEK2 ZAC
FASTENERS (@ 1'-0" O.C.)

FIELD CUT PANEL AND
TURN UP 90°


TRAP-TEE PANEL
THERMAL SPACER

STRUCTURAL ROOF
MEMBER

WALL FASTENER



RAKE SUPPORT CLEAT
(MT-156)



RAKE TRIM
(MT-183)

- NOTES:**
1. MT-183 (Rake Trim), MT-156 (Rake Support Cleat) and MT-SLOT-300 (Starter Zee for 300 Series Panel with 1/4" Offset Clip) to run from eave to ridge.
 2. Attach MT-SLOT-300 (Starter Zee for 300 Series Panel with 1/4" Offset Clip) to rake angle with 1/4-14 x 1 1/4" HWH Tek2 w/ Shoulder Fasteners at 1'-0" O.C.
 3. Apply two (2) continuous beads of 3/16" x 7/8" Double Bead Tape Sealant to the vertical leg of the Trap-Tee panel. Install Trap Tee panel and hold in place on the Starter Zee with clamps. Fasten panel to Starter Zee with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners at 1'-0" O.C.
 4. Apply a continuous bead of 3/32" x 1" Roll Tape Sealant to the top of the Starter Zee and attach MT-183 (Rake Trim) with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners at 1'-0" O.C.
 5. Trim pieces lap 2". Apply 3/32" x 3/8" Butyl Tape or Butyl Tube Sealant in trim laps and Fasten to trims.

TRAP-TEE PANEL

1/4-14 X 1 1/4" TEK2
ZAC FASTENERS
(@ 1'-0" O.C.)

RAKE TRIM
(MT-183)

RAKE SUPPORT
CLEAT (MT-156)

43D POP RIVET
(@ MAJOR RIBS)

OUTSIDE CLOSURE
(RECOMMENDED)

FIELD CUT PANEL AND
TURN UP 90°

WALL FASTENER
WALL PANEL

3/32" X 1" ROLL TAPE SEALANT
(CONT. ALONG LENGTH OF RAKE)

1/4-14 X 1 1/4" HWH TEK2 W/ SHOULDER
FASTENER (@ 1'-0" O.C.)

STARTER ZEE FOR 300 SERIES PANEL
W/ 1/4" OFFSET CLIP (MT-SLOT-300)



THERMAL SPACER

*NOTE: SOME TRIM ITEMS
AND FASTENERS HAVE BEEN
REMOVED FOR CLARITY OF
ISOMETRIC DETAIL.


2 ROWS OF 3/16" X 7/8"
DOUBLE BEAD TAPE SEALANT
(CONT. ALONG LENGTH
OF RAKE)

RAKE ANGLE

STRUCTURAL ROOF
MEMBER




REGLET TRIM (MT-58)




STANDARD SIDEWALL TRIM (MT-34)

- NOTES:**
1. MT-34 (Standard Side-Wall Trim) to run from Eave to Ridge.
 2. Attach MT-SLOT-300 (Starter Zee for 300 Series Panel with 1/4" Offset Clip) to rake angle with 1/4-14 x 1 1/4" HWH Tek2 with Shoulder Fasteners at 1'-0" O.C.
 3. Apply two (2) continuous beads of 3/16" x 7/8" Double Bead Tape Sealant to the vertical leg of the Trap-Tee panel. Install Trap Tee panel and hold in place on the Starter Zee with clamps. Fasten panel to Starter Zee with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners at 1'-0" O.C.
 4. Apply a continuous run of 3/32" x 1" Roll Tape Sealant to the top of the Starter Zee and attach MT-34 (Standard Side-Wall Trim) with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners at 1'-0" O.C.
 5. Trim pieces lap 2". Apply 3/32" x 3/8" Butyl Tape or Butyl Tube Sealant in trim laps and Fasten to trims.


*NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.









- NOTES:**
1. MT-34 (Standard Side-Wall Trim) to run from Eave to Ridge.
 2. Attach MT-SLOT-300 (Starter Zee for 300 Series Panel with 1/4" Offset Clip) to rake angle with 1/4-14 x 1 1/4" HWH Tek2 with Shoulder Fasteners at 1'-0" O.C.
 3. Apply two (2) continuous beads of 3/16" x 7/8" Double Bead Tape Sealant to the vertical leg of the Trap-Tee panel. Install Trap Tee panel and hold in place on the Starter Zee with clamps. Fasten panel to Starter Zee with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners at 1'-0" O.C.
 4. Apply a continuous run of 3/32" x 1" Roll Tape Sealant to the top of the Starter Zee and attach MT-34 (Standard Side-Wall Trim) with 1/4-14 x 1 1/4" Tek2 ZAC Fasteners at 1'-0" O.C.
 5. Trim pieces lap 2". Apply 3/32" x 3/8" Butyl Tape or Butyl Tube Sealant in trim laps and Fasten to trims.

*NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.









- NOTES:**
1. MT-2 (Ridge Cap) and MT-38 (Standard Offset Cleat) to run from out of wall to out of wall.
 2. Install Trap-Tee panels and apply a 3/16" x 7/8" Double Bead Tape Sealant to the bottom and sides of the Outside Closure.
 3. Install Outside Closures and secure to panel with (6) 1/4-14 x 1 1/4" Tek2 ZAC Fasteners, making sure to fasten through into the MT-202 (3/8" Offset Hip/Ridge Plate) and (2) 1/4-14 x 7/8" LapTek Zac Fasteners into the angled sides of Outside Closures.
 4. MT-2 (Ridge Cap) laps 2". Apply 3/32" x 1" Butyl Tape and Pop Rivet trims to MT-38 (Standard Offset Cleat) with Pop Rivets at Laps.
 5. Apply a continuous bead of 3/32" x 1" Butyl Tape to the top of the Outside Closures. Set Standard Offset Cleat in place and attach with 1/4-14 x 7/8" Lap Tek Fasteners at 6" O.C. Secure Ridge Cap (MT-2) with 43D Pop Rivets at Trim Laps.





*NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.



- NOTES:**
1. MT-2 (Ridge Cap) and MT-38 (Standard Offset Cleat) to run from out of wall to out of wall.
 2. Install Trap-Tee panels and apply a 3/16" x 7/8" Double Bead Tape Sealant to the bottom and sides of the Outside Closure.
 3. Install Outside Closures and secure to panel with (6) 1/4-14 x 1 1/4" Tek2 ZAC Fasteners, making sure to fasten through into the MT-202 (3/8" Offset Hip/Ridge Plate) and (2) 1/4-14 x 7/8" LapTek Zac Fasteners into the angled sides of Outside Closures.
 4. MT-2 (Ridge Cap) laps 2". Apply 3/32" x 1" Butyl Tape and Pop Rivet trims to MT-38 (Standard Offset Cleat) with Pop Rivets at Laps.
 5. Apply a continuous bead of 3/32" x 1" Butyl Tape to the top of the Outside Closures. Set Standard Offset Cleat in place and attach with 1/4-14 x 7/8" Lap Tek Fasteners at 6" O.C. Secure Ridge Cap (MT-2) with 43D Pop Rivets at Trim Laps.




- NOTES:**
1. MT-189 (Floating Ridge Cap) to run from out of wall to out of wall.
 2. Install Trap-Tee panels and apply a 3/16" x 7/8" Double Bead Tape Sealant to the bottom and sides of the Outside Closure.
 3. Install Outside Closures and secure to panel with (9) 1/4-14 x 1 1/4" HWH Tek2 ZAC Fasteners, making sure to fasten through into the Back-Up Plate.
 4. MT-189 (Floating Ridge Cap) laps 2". Apply 3/32" x 1" Butyl Tape and attach to Outside Closures with 1/4-14 x 7/8" LapTek ZAC Fasteners at 0'-6" O.C.




*NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.


- NOTES:**
1. MT-189 (Floating Ridge Cap) to run from out of wall to out of wall.
 2. Install Trap-Tee panels and apply a 3/16" x 7/8" Double Bead Tape Sealant to the bottom and sides of the Outside Closure.
 3. Install Outside Closures and secure to panel with (9) 1/4-14 x 1 1/4" HWH Tek2 ZAC Fasteners, making sure to fasten through into the Back-Up Plate.
 4. MT-189 (Floating Ridge Cap) laps 2". Apply 3/32" x 1" Butyl Tape and attach to Outside Closures with 1/4-14 x 7/8" LapTek ZAC Fasteners at 0'-6" O.C.




- NOTES:**
1. MT-35 (Standard Headwall Trim) to run from out of wall to out of wall.
 2. Install Trap Tee panels and apply a 3/16" x 7/8" Double Bead Tape Sealant to the bottom and sides of the Outside Closure.
 3. Install Outside Closures and secure to panel with (9) 1/4-14 x 1 1/4" HWH Tek2 ZAC Fasteners, making sure to fasten through into the Back-Up Plate.
 4. MT-35 (Standard Headwall Trim) laps 2". Apply a continuous bead of 3/32" x 1" Butyl Tape along the top of the Outside Closures and attach with 1/4-14 x 7/8" Lap Tek Fasteners at 6" O.C.




*NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.




- NOTES:**
1. Standard Headwall Trim (MT-35) to run from out of wall to out of wall.
 2. Install Trap-Tee panels and apply a 3/16" x 7/8" Double Bead Tape Sealant to the bottom and sides of the Outside Closure.
 3. Install Outside Closures and secure to panel with (9) 1/4-14 x 1 1/4" HWH Tek2 ZAC Fasteners, making sure to fasten through into the Back-Up Plate and through sides of seams.
 4. Standard Headwall Trim (MT-35) laps 2". Apply a continuous bead of 3/32" x 1" Butyl Tape along the top of the Outside Closures and attach with 1/4-14 x 7/8" Lap Tek Fasteners at 6" O.C.




*NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.




- NOTES:**
1. High Eave Trim (MT-25) Standard Offset Cleat (MT-38) and ML/MXM Low Eave Plate to run from out of wall to out of wall.
 2. Install Trap Tee panels and apply a 3/16" x 7/8" Double Bead Tape Sealant to the bottom and sides of the Outside Closure.
 3. Install Outside Closures and secure to panel with (6) 1/4-14 x 1 1/4" Tek2 ZAC Fasteners into Low Eave Plate, (2) 1/4-14 x 7/8" LapTek ZAC Fasteners and (1) 1/4-14 x 1 1/4" Tek2 ZAC Fastener in the vertical seam portion of the closure.
 4. Apply a continuous bead of 3/32" x 1" Butyl Tape to the top of the Outside Closures.
 5. High Eave Trim (MT-25) laps 2". Attach to the Outside Closures with 1/4-14 x 7/8" LapTek ZAC Fasteners at 0'-6" O.C.






*NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.




- NOTES:** 1. Cut hole in panel 1" larger than pipe diameter. If installing over a solid substrate, over-cut hole in substrate so fastener do not pin system from thermal movement.
2. Cut hole in top of Dektite Boot so that it fits snugly around pipe. Apply a 3/16" Ø bead of Tube Butyl sealant around the base flange of boot. Secure to panel with 1/4-14 x 7/8" Lap Tek ZAC fasteners 2" O.C.
3. Dektite boot MUST fit in pan of panel. Do not fasten to standing seams.



NOTE: SOME TRIM ITEMS AND FASTENERS HAVE BEEN REMOVED FOR CLARITY OF ISOMETRIC DETAIL.



NOTE: 1. Apply 3/32" x 3/8" Roll Tape Sealant or a 3/16" Dia. bead of Tube Butyl 1 1/2" back from the edge of the trim. Also, apply a piece of tape sealant or bead of Tube Butyl as a Pigtail to completely seal joint.
2. Notch the hems on the upper trim piece 2" so that the trim will fit flat in the lap joint.
3. Secure trim laps with Pop Rivets as shown above.



NOTE: 1. Apply 3/32" x 1" Roll Tape Sealant or a 3/16" Dia. bead of Tube Butyl 1 1/2" back from the edge of the trim.
 2. Notch the hems on the upper trim piece 2" so that the trim will fit flat in the lap joint.
 3. Secure trim laps with Pop Rivets as shown above.



☆ MANUFACTURING LOCATIONS ● SERVICE CENTERS ★ MANUFACTURING AND SERVICE CENTER



CORPORATE OFFICE
1500 HAMILTON RD.
BOSSIER CITY, LA 71111

MANUFACTURING LOCATIONS

ADELANTO, CA	ASHBURN, GA	BOSSIER CITY, LA	CLINTON, IL	DIAMOND, MO
HOUSTON, TX	LEWISPORT, KY	LOCKHART, TX	MARSHALL, MI	MAUSTON, WI
MERKEL, TX	PEACHTREE CITY, GA	SUNNYVALE, TX	WINCHESTER, VA	

McELROY METAL
SERVICE
CENTER
EMPLOYEE OWNED

17031 Koala Road Adelanto, CA 92301	5215 Leo St. Alexandria, LA 71301	1007 Wilso Dr, Baltimore, MD 21223	1500 Hamilton Rd. Bossier City, LA 71111
3052 Yadkin Road Chesapeake, VA 23323	9476 Meadowbrook Rd. Clinton, IL 61727	3215 Highway 59 Diamond, MO 64840	390 N. Valley Dell Dr. Fenton, MO 63026
409 Lovejoy Road Ft. Walton Beach, FL 32548	3014 Lincoln Court Garland, TX 75041	1440 Aldine Bender Road Houston, TX 77032	10504 E. 59th Street Indianapolis, IN 46236
32 Industrial Circle Lancaster, PA 17601	9435 US Hwy. 60 W. Lewisport, KY 42351	2701 Cahill Street Lockhart, TX 78644	1020 Veterans Street Mauston, WI 53948
5123 Terminal Dr. McFarland, WI 53558	514 Cave Road Nashville, TN 37210	8304 Hwy. 70 E. North Little Rock, AR 72117	613 North Bierdeman Rd. Pearl, MS 39208
8511 Industrial Drive Pearland, TX 77584	2755 Hwy 60 Pendergrass, GA 30567	7450 Tower Street Richland Hills, TX 76118	8200 Berry Ave. Suite 100 Sacramento, CA 95828
1365 Dean Forest Rd. Savannah, GA 31405	7355 Oakley Industrial Blvd. Union City, GA 30291	1144 Silstar Rd. West Columbia, SC 29170	325 McGhee Rd. Winchester, VA 22603

Website: www.mcelroymetal.com • E-mail: info@mcelroymetal.com